

Technical Newsletter

#tnl2016-0021tc

給要上切割機研修課程「階段 3 (或維修課程 2)」的顧客們

首 先

在 2012 年 1 月 1 日以後出貨的切割機中、有對應機械指令^{※1} (CE marking[※]) 的機台、提升了針對安全的設計變更。因此、在此通知研修時所進行的一些項目將不再實施。

<這次通隻的對象機台>

客戶所持有的設備	2012 年 1 月 1 日前出貨	2012 年 1 月 1 日以後出貨	
		機械指令 對應機台	機械指令 非對應機台
DAD322	對象外	對象	對象外
3000 系列 ^{※3}	對象外	對象	對象外
6000 系列 ^{※3}	對象外	對象	對象外

※1 對於機械有規定「必須的安全事項要求」。


※2 對於輸出到歐洲的設備適用「必須的安全事項要求」的必須有標示做為證明，該項作業被視為必須執行的義務。

※3 由於 DAD3650, DFD6341, DFD6560 的標諄規格有適用該安全事項，如過是以標諄規格出貨的設備將都在對象內。

對象機台的識別方法

對象機台在外蓋的安全開關附近有貼下面的貼紙。

各機台貼紙的確切位置請參考附件資料。



該維修作業

對象機台在實施下面的對象作業時會觸動安全機構 (inter lock)、軸電源會被切斷, 因此客戶無法進行該維修設定作業。

機 台	維修作業內容
DAD322 3000 系列	<ul style="list-style-type: none">● 顯微鏡交換● 精度調整● spindle 交換
6000 系列	<ul style="list-style-type: none">● 顯微鏡交換● 搬送調整● 精度調整● spindle 交換● spinner seal 交換







對應方法

需要進行上述作業時請聯絡敝社工程師進行。



詢 問

關於本件變更的詢問可以聯絡研修中心 (trainctr@disco.co.jp) 或敝社的業務負責人。




添附資料：各機台別的貼紙位置

機 台	貼紙位置		
DAD322	 <p style="text-align: center;">右側面</p>	 <p style="text-align: center;">前面</p>	 <p style="text-align: center;">左側面</p>
DAD3220 DAD3230 DAD3430	 <p style="text-align: center;">右側面</p>	 <p style="text-align: center;">前面</p>	 <p style="text-align: center;">左側面</p>


添附資料：各機台別の貼紙位置（續）

機 台	貼紙位置
DAD3350	 <p>左側面</p> <p>右側面</p>
DAD3650	 <p>左側面</p> <p>前面</p> <p>右側面</p> <p>背面</p>


添附資料：各機台別の貼紙位置（續）

機 台	貼紙位置		
DFD6240	 <p data-bbox="507 967 571 990">左側面</p>	 <p data-bbox="906 967 954 990">前面</p>	 <p data-bbox="1251 967 1299 990">背面</p>





添附資料：各機台別の貼紙位置（續）

機 台	貼紙位置
DFD6340	 <p>The diagrams illustrate the sticker placement for the DFD6340 machine from four perspectives:</p> <ul style="list-style-type: none"> 左側面 (Left Side): A sticker is located on the lower front panel of the left-side cabinet. 前面 (Front): Two stickers are located on the front panel: one on the lower left side and one on the lower right side. 右側面 (Right Side): A sticker is located on the lower front panel of the right-side cabinet. 背面 (Back): A sticker is located on the upper back panel, centered above the main control area.


添附資料：各機台別の貼紙位置（續）

機 台	貼紙位置
DFD6341	 <p>The diagram illustrates the sticker placement for the DFD6341 machine from three perspectives:</p> <ul style="list-style-type: none"> 左側面 (Left Side View): A sticker is located on the lower part of the left-side panel. 右側面 (Right Side View): A sticker is located on the lower part of the right-side panel. 背面 (Back View): A sticker is located on the back panel, centered horizontally and positioned above the main control area.




添附資料：各機台別的貼紙位置（續）

機 台	貼紙位置
<p>DFD6360 DFD6361</p>	<div style="display: flex; flex-wrap: wrap; justify-content: space-around;"> <div style="text-align: center;">  <p>左側面</p> </div> <div style="text-align: center;">  <p>前面</p> </div> <div style="text-align: center;">  <p>右側面</p> </div> <div style="text-align: center;">  <p>背面</p> </div> </div>

添附資料：各機台別的貼紙位置（續）

機 台	貼紙位置
DFD6362	 <p>The diagrams illustrate the sticker placement for the DFD6362 machine from four perspectives:</p> <ul style="list-style-type: none"> 左側面 (Left Side): A sticker is located on the upper left panel, near a control panel. 前面 (Front): Two stickers are shown: one on the top left panel and another on the lower right panel, near the paper tray. 右側面 (Right Side): A sticker is located on the lower right panel, near the paper tray. 背面 (Back): A sticker is located on the upper right panel, near a ventilation grille.

添附資料：各機台別の貼紙位置（續）

機 台	貼紙位置		
DFD6560	 <p data-bbox="523 887 592 913">左側面</p>	 <p data-bbox="895 887 943 913">前面</p>	 <p data-bbox="1203 887 1267 913">右側面</p>

= End =